

- This drawing is to be read in conjunction with all related Architectural, Engineering, Specialist and Detail drawings and relevant information.

-Note for site construction team leader: Please study these drawings along with all of the other project drawings before site work commences. Report any omissions, discrepencies or questions to SIPbuildUK straight away to avoid being delayed on site.

- All panels must be thoroughly glued and screwed into position.

- A suitable expanding glue such as that made by Apollo Adhesives or similar must be used.

- Panels should be screwed not nailed. A screw gun can be used for efficiency.

- Ensure that an even bead of glue is applied to the relevant faces prior to fixing panels together. Remember: The glue bond is the building's strength.

© Edward Halford Ltd., 2012

E260 Dwg No. Revision Client SIPBuildUK Scale N/A @ A1 Job Title Raithwaite Hall Date 07.04.13 Sandsend, Whitby RWH P26